




**R3 ELECTRIC STRIKE
INTERNAL MEMORY VERSION
INSTALLATION GUIDE**



1. In the prepared hole in the door frame insert electric strike **with the electric connector downwards** (see draw below).
2. Connect electric strike to power and check if it works.
3. Adjust door clearance with external ratchet.
4. Check the internal memory function by temporarily applying a voltage. After the cessation of the electrical pulse door should be able to open. After closing the door should be locked again.



Poznań, 2016-01-04

Elektra Plus Maciej Połczyński

ul. Grudzieniec 66, 60-601 Poznań
tel/fax: (+48) 618484178 (Customer Service)
tel: (+48) 618484177 (Technical Support)
e-mail: biuro@elektraplus.net
internet: www.elektraplus.net